



CFS LOAD-BEARING
STEEL STUD WALL -
SIZE AND GAUGE AS
PER ENGINEERING.
STUDS TO BE ALIGNED
WITH JOISTS OVER.

**COLD-FORMED STEEL STUD
FRAMING - BOTTOM TRACK TO
CFS JOIST CONNECTION**
{INSULATIONS AND OTHER BUILDING COMPONENTS
NOT SHOWN FOR CLARITY.}

PLYWOOD
SUB-FLOOR

CFS JOISTS
FLOOR ASSEMBLY -
SIZE AND GAUGE AS
PER ENGINEERING

CFS
BOTTOM
TRACK

CFS RIM
TRACK

SCREW FASTENER TO
SUB-FLOOR AT
PRE-PUNCHED
LOCATIONS

CFS WEB
STIFFENER

P: 1-877-251-6875
F: 1-866-873-0360
INFO@TRUSSES.CA



**CFS STUD
FRAMING
BOTTOM TRACK TO
CFS JOIST
CONNECTION**