



GUSSET PLATE CONNECTION FOR WIND BRACE

TOP TRACK

BOTTOM TRACK

HOLD DOWN CLIP CONNECTION

WALL STUDS - SIZE AND GAUGE AS PER ENGINEERING

FLAT STRAP X-BRACING - SIZE AND GAUGE AS REQUIRED FOR BUILDING DESIGN.

CRITICAL STUD - AT EACH SIDE OF X-BRACE FOR INCREASED VERTICAL LOAD CREATED BY DIAGONAL STRAP.

CONTINUOUS BRIDGING - SPACED AS REQUIRED

LOAD BEARING WALL - COMPLETE WITH FLAT STRAP X-BRACING AS PER BUILDING DESIGN REQUIREMENTS.

P: 1-877-251-6875
 F: 1-866-873-0360
 INFO@TRUSSES.CA



CFS STUD
 FRAMING
 LATERAL BRACE
 DETAIL